Reducing Noise In The Cab

SAFETY.CAT.COM™

Toolbox Talks are intended to facilitate health and safety discussions on the job site. For additional Toolbox Talks, please visit SAFETY.CAT.COM™.

TOPIC: Reducing Noise In The Cab

Inspect Equipment

- Purchase equipment only after testing noise levels in the cab
- Maintain and regularly inspect window and door seals to help manage outside noise
- Find a way to control sources of noise such as the engine, transmission, and hydraulic brakes
- Regularly monitor noise levels

Upgrade and Care for Equipment

- Replace older equipment with new materials and technology
- Install noise-reducing floor mats, insulation, special glass, and any other materials that could help reduce noise
- Replace or relocate mufflers or exhaust pipes whenever necessary
- Take proper care of the air conditioning system to ensure its availability

Make Others Aware

- Inform other drivers of the potential noise hazards, and keep them aware of prevention methods
- Train drivers to identify and report changes that could have a negative effect on noise levels in the cab

Discussion Date: _____

Employee Participants:

_____

_____

_____

_____

_____

_____

_____

_____

_____

_____

The material in this document is provided for informational purposes only and not as a comprehensive or exhaustive resource on this topic. This material has been compiled from a multitude of sources believed to be accurate; however, Caterpillar Inc. assumes no responsibility for the accuracy or currency of this information and encourages you to consult experts in this area for more information. In no event does the content of this document supersede any applicable local, state, or federal statutes or regulations.

CAT, CATERPILLAR, their respective logos, "Caterpillar Yellow" and the POWER EDGE trade dress, as well as corporate and product identity used herein, are trademarks of Caterpillar and may not be used without permission. © 2009 Caterpillar All Rights Reserved

CATERPILLAR®